

MAGNILUMEN

Fluorescent Retrofit Kit Installation



*Working together
to get the job done!*

STEP 1: Turn off power and remove the lamps and ballast cover. Disconnect the incoming power from the ballast, trim the tombstone wires, and remove the ballast.



STEP 2: Place the Magnilumen magnetic driver into the fixture, and ground the driver.



STEP 3: Connect the new driver to the incoming power.



STEP 4: Be sure to keep your wiring neat.



STEP 5: Replace the ballast cover and connect the wire harness so it is accessible.



STEP 6: Clip Magnilumen's magnetic mounting brackets to the back of the LED boards.



STEP 7: Place the magnetized LED boards into the fixture.



STEP 8: Connect the wire harness to the LED boards.



STEP 9: Turn on your power to test your newly retrofitted fixture.



STEP 10: Apply the retrofit sticker.



STEP 11: Adjust the LED boards to maximize your light beam spread.



STEP 12: Installation is complete!

