




THE SUPPLY SOURCE

• Plumbing • Electrical • HVAC • Hardware



Electrical Panels & Breakers



3 PHASE LOAD CENTER

1660043



**BR INDOOR MAIN BREAKER
LOADCENTER 100A 12-20**

643231



**BR INDOOR MAIN BREAKER
LOADCENTER 200A 20-40**

643252



**BR INDOOR MAIN BREAKER
LOADCENTER 200A 30-40**

643259



**BR INDOOR MAIN BREAKER
LOADCENTER 200A 40-40**

643266



**BR INDOOR MB
LOADCENTER VALUE PACK
100A 20-20**

643268





**BR INDOOR MB
LOADCENTER VALUE PACK
200A 30-40**

643269



**BR INDOOR MAIN BREAKER
LOADCENTER 100A 20-20**

643270



**BR INDOOR MAIN BREAKER
LOADCENTER 100A 30-30**

643271



**BR INDOOR MAIN BREAKER
LOADCENTER 200A 20-40**

643272



**BR INDOOR MAIN BREAKER
LOADCENTER 200A 30-40**

643273



**BR INDOOR MAIN BREAKER
LOADCENTER 200A 40-40**

643274





**BR INDOOR MAIN BREAKER
LOADCENTER 100 AMPS 20
TO 20 CIRCUITS**

643462



**BR OUTDOOR MAIN BREAKER
LOADCENTER 100A 12 24**

643481



**BR OUTDOOR MAIN
BREAKER LOADCENTER
100A 20-24**

643482



**BR OUTDOOR MAIN
BREAKER LOADCENTER
200A 20-40**

643483



**BR OUTDOOR MAIN BREAKER
METER/PANEL HOUSE
COMBO 125A 2-4**

643504



**BR OUTDOOR MAIN
BREAKER METER AND
PANEL HOUSE COMBO 200
AMPS**

643511





**BR OUTDOOR MAIN
BREAKER METER AND
PANEL HOUSE COMBO 100
AMPS 12 TO 24 CIRCUITS**

643532



**BR OUTDOOR MAIN BREAKER
METER AND PANEL HOUSE
COMBO 200 AMPS 20 TO 40
CIRCUITS**

643539



**AUTOMATIC TRANSFER
SWITCH FOR GENERATOR
READY LOADCENTER**

660056



**BR SERIES 1 POLE ARC
FAULT BREAKER 15 AMPS**

605279



**BQ QUAD BREAKER ONE 2
POLE 30A X TWO 1 POLE 20A
IT**

606019



**BQ QUAD BREAKER ONE 2
POLE 40 AMP AND TWO 1
POLE 20 AMP INDEPENDENT
TRIP**


606026






**BQ QUAD BREAKER ONE 2
POLE 20 AMP AND ONE 2
POLE 30 AMP INDEPENDENT
TRIP**

606040




**BQ QUAD BREAKER TWO 2
POLE 30 AMP INDEPENDENT
TRIP**

606043




**BQ QUAD BREAKER ONE 2
POLE 30A X ONE 2 POLE 40A
IT**

606044



**BQ QUAD BREAKER TWO 2
POLE 40A IT**

606045



**BQ QUAD BREAKER ONE 2
POLE 30 AMP AND ONE 2
POLE 50 AMP INDEPENDENT
TRIP**

606047



**ARC FAULT BREAKER
SINGLE POLE 120VAC**

608127





**ARC FAULT BREAKER
SINGLE POLE 120VAC**

608128



**AC/HEATING DISCONNECT
RAINTIGHT 60A NON-FUSE
WITH GFCI**

643046



**AC/HTG DISCONNECT
RAINTIGHT 60A NON FUSE
WITH 1/2 IN. WIRE HARNESS**

643047



**AC/HTG DISCONNECT
RAINTIGHT 60A NON FUSE
WITH 3/4 IN. WIRE HARNESS**

643048



**AC DISCONNECT RAIN TIGHT
3-PHASE 60A 600V NON-FUSE**

643049



**AC DISCONNECT NON-
METALLIC 30A FUSIBLE**

643050





AC DISCONNECT NON-METALLIC 60A FUSIBLE

643051



BR OUTDOOR METER/PANEL COMBO 125A 4-8

643052



BR OUTDOOR METER/PANEL COMBO 200A 4-8

643053



BR OUTDOOR METER/PANEL COMBO 200A 8-16

643054



AC DISCONNECT RAIN TIGHT 60A


641005



AC DISCONNECT RAIN TIGHT 60A NON FUSE

643009





**AC DISCONNECT RAIN TIGHT
30A 2 FUSE**

643014



**AC DISCONNECT RAIN TIGHT
60A 2 FUSE**

643021



**AC DISCONNECT NON
METALLIC 60A NON FUSE**

643028




**AC DISCONNECT NON-
FUSIBLE RAIN TIGHT 60AMP
METAL**

660860



**AC DISCONNECT FUSIBLE
RAIN TIGHT 60AMP METAL**

660864



**AC DISCONNECT FACTORY
TRIP SWITCH INSTALLED
RAIN TIGHT**

660869





**ALUMINUM ENTRANCE
ELBOW 1/2 IN.**

623211



**ALUMINUM ENTRANCE
ELBOW 3/4 IN.**

623218



**ASSEMBLED ALUMINUM
CONDUIT BODY 1/2 IN.**

625022



**ASSEMBLED ALUMINUM
CONDUIT BODY 3/4 IN.**

625027



**ASSEMBLED ALUMINUM
CONDUIT BODY 1 IN.**

625031



**ASSEMBLED ALUMINUM
CONDUIT BODY 1-1/4 IN.**

625033





**ASSEMBLED ALUMINUM
CONDUIT BODY 1-1/2 IN.**

625035



**ASSEMBLED ALUMINUM
CONDUIT BODY 2 IN.**

625036



AUTO STYLE FUSE 36V 3A

791003

Min. Qty. sold: 5
In multiples of: 5



AUTO STYLE FUSE 36V 5A

791004

Min. Qty. sold: 5
In multiples of: 5



BOX GROUNDING CLIP

624030

Min. Qty. sold: 100
In multiples of: 100



**5/8 IN. X 8 FT. GALVANIZED
GROUND ROD**

643602

Min. Qty. sold: 5
In multiples of: 5

